

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN. IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

NOTES:

FIXTURES AND SYSTEM CONNECTORS MUST BE INSTALLED PRIOR TO END CAP MOUNTING. PLENUM END CAPS MAY BE INSTALLED TO PLENUM COVER (AS SHOWN BELOW) OR TO THE STRAIGHT EXTENSION U-ANGLES: REFER TO INSTRUCTION SHEET 510259.

INSTRUCTIONS:

1. MOUNT END CAP TO PLENUM COVER OR U-ANGLE WITH (2) 1/4-20 SCREWS AND NUTS FOUND IN POLYBAG.
2. WHEN MOUNTING TO THE END OF A FIXTURE, INSERT A NYLON DART FASTENER THRU END CAP AND INTO END HEADER OF FIXTURE.

