

INSTALLATION  
INSTRUCTIONS

FIXTURE TYPE \_\_\_\_\_

DIFFUSER WALL ANGLE  
WALLSLOT 8400

P/C 510577-0000

PG. 1 OF 1

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.  
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

**NOTES: PRIOR TO STARTING**

- A. WALL SURFACE SHOULD BE FINISHED A MINIMUM OF 7" ABOVE CEILING.
- B. DIFFUSER WALL ANGLES ARE SHIPPED IN 96" LENGTHS: SAWCUT TO SUIT FIELD CONDITIONS. **DO NOT DISCARD LEFTOVER CUT ANGLES.**
- C. INSTALL SUPPORT RAILS BEFORE MOUNTING DIFFUSER WALL ANGLES; REFER TO INSTRUCTION SHEET 510573.

**INSTRUCTIONS:**

**IMPORTANT: DIFFUSER WALL ANGLES ARE USED ONLY WHEN THERE IS A LENS REQUIRED IN THE R (RECESSED) POSITION.**

- 1. CHALK A LEVEL LINE 2-9/16" BELOW BOTTOM EDGE OF SUPPORT RAIL ALONG FULL LENGTH OF WALL FOR POSITIONING THE BOTTOM EDGE OF THE WALL ANGLE.
- 2. PLACE BOTTOM EDGE OF WALL ANGLE ON CHALK LINE AND FASTEN TO WALL WITH 6 PENNY NAILS OR EQUAL. SHIM BEHIND WALL ANGLES WHEN NECESSARY TO FORM A CONTINUOUS STRAIGHT LINE.
- 3. BUTT EDGES OF WALL ANGLES AT CORNERS AS SHOWN.

