

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

GENERAL NOTES:

ALTHOUGH THE P-ID-93M00 FIXTURE IS SHOWN. INSTALLATION OF BAFFLE IS THE SAME FOR P-ID-82M00 FIXTURES.
BAFFLES ARE INSTALLED AFTER FIXTURES HAVE BEEN HUNG AND WIRING HAS BEEN COMPLETED. REFER TO FIXTURE INSTRUCTION SHEETS 510560 OR 510561

INSTRUCTIONS:

1. REMOVE BAFFLES FROM CARTON AND LEAVE POLYBAG ON UNTIL READY FOR INSTALLATION.
2. LIFT BAFFLE UPWARD AND INSERT INTO FIXTURE OPENING UNTIL FORM ON BAFFLE SEATS INTO BOTTOM OF FIXTURE HOUSING EDGE. BAFFLE SHOULD BE CENTERED IN FIXTURE OPENING AND SLIGHTLY RECESSED FROM BOTTOM OF FIXTURE AFTER INSTALLATION.
3. CLEAN BAFFLE PER CLEANING LABEL LOCATED ON BAFFLE.

