

INSTALLATION
INSTRUCTIONS

FIXTURE TYPE _____

P-ID-8200, 9300 & 9400
BAFFLE ASSEMBLY

P/C 510416-3000

PG. 1 OF 1

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

GENERAL NOTES:

ALTHOUGH THE P-ID-9300 FIXTURE IS SHOWN. INSTALLATION OF BAFFLE IS THE SAME FOR P-ID-8200 AND P-ID-9400 FIXTURES.
BAFFLES ARE INSTALLED AFTER FIXTURES HAVE BEEN HUNG AND WIRING HAS BEEN COMPLETED. REFER TO FIXTURE INSTRUCTION SHEETS 510414, 510415 OR 510457

INSTRUCTIONS:

1. REMOVE BAFFLES FROM CARTON AND LEAVE POLYBAG ON UNTIL READY FOR INSTALLATION.
2. REMOVE BAFFLE FROM BAG AND ATTACH BOTH SAFETY TETHERS LOCATED INSIDE OF FIXTURE TO 1ST BLADE AT ONE END OF BAFFLE AND 3RD BLADE IN FROM OTHER END OF BAFFLE AS SHOWN IN DETAIL BELOW. MAKE SURE THAT TETHER CLASP HAS BEEN SECURED.
3. SWING BAFFLE UPWARD AND INSERT INTO FIXTURE OPENING UNTIL SPRING CLIPS ON BAFFLE RAILS SNAP INTO BOTTOM OF FIXTURE HOUSING. BAFFLE SHOULD BE CENTERED IN FIXTURE OPENING AND SLIGHTLY RECESSED FROM BOTTOM OF FIXTURE AFTER INSTALLATION.
4. BAFFLES MAY BE REMOVED FOR CLEANING BY GENTLY GRASPING BLADES AND PULLING DOWNWARD UNTIL SPRING CLIPS DISENGAGE FROM FIXTURE. CLEAN BAFFLE PER CLEANING LABEL LOCATED ON BAFFLE.

