

INSTALLATION
INSTRUCTIONS

FIXTURE TYPE _____

P6S/ACC ASSY
P-I/P-ID-33,33JR,36,36JR,
37,37JR,P-D-38S,38M,38L
PG. 1 OF 1

P/C **510358-7000**

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN. IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

GENERAL NOTES:

1. The P6S/ACC Cable assemblies are made to install directly into a 3-1/2" x 2-1/8" deep octagonal outlet box mounted flush to ceiling. Mounting Hickey is supplied by Litecontrol for attachment to outlet box as shown in View. 1/2" Trade size fittings are supplied by contractor.

WARNING:

The National Electric Code requires that any fixture weighing more than 50 pounds be independently supported of an outlet box.

2. These fixture supports are to be used only in conjunction with LITECONTROL products for which they were furnished: DO NOT use them for support of other items or in any fashion contrary to this instruction sheet.
3. Dual feed cord option may be used when two or more switching requirements are needed.
4. This instruction sheet is used in conjunction with Fixture Installation sheets part numbered: 510357, 510359, 510421, 510422, 510425, 510426, 510427, 510428, 510431, 510432, 510422, 510434 or 510579.

INSTRUCTIONS:

1. Mount Hickey to inside of outlet box as shown in Views.
2. Cut a piece of feed cord (shipped separately) equal to the distance from ceiling to top of fixture and add 24". Cut two lengths of feed cord for dual feed/two circuit option.
3. Insert one end of feed cord(s) into outlet box and make wiring connections.
4. Slide Canopy, Slip-Ring and Thread Cover onto P6S stem. Thread a locknut onto bottom thread. For dual feed option, insert snap bushing into off-center hole in canopy.
5. Loosely thread a setscrew into hole in slip-ring with Hex Key provided.
6. Insert feed cord thru stem while hooking upper locknuts onto hickey. For dual feed option, insert 2nd feed cord thru snap bushing in canopy. Tighten lower locknut up against bottom of hickey.
7. Slide Canopy up the stem until flush against ceiling and with slip-ring up against canopy, tighten setscrew with hex key.
8. Slide the Cable Retaining plate over center feed cord and then attach to bottom of stem with threaded coupling. Tighten bottom locknut to top of retaining plate and slide thread cover down against locknut. For dual feed option, feed cord is run outside the Cable retaining plate.
9. Refer to Fixture installation sheet for mounting fixture to cables.

