

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

GENERAL NOTES: (READ SHEETS COMPLETELY BEFORE STARTING)

1. End caps are shipped separately and used with Fixture Installation Instruction sheet 510543.
2. End Caps are attached to both ends of an individually mounted fixture and at both ends of a row of fixtures.
3. End Caps are shipped with Baffle End Covers; Refer to Fixture Instructions for installation.

INSTRUCTIONS:

Mount End Caps to fixture end headers with (2) 8-32 nuts as shown.

