

INSTALLATION  
INSTRUCTIONS

FIXTURE TYPE \_\_\_\_\_

END CAPS  
S-D, P-D, W-D,  
P-S/D-4400

P/C 510473-0000

DATE: 1-14-05

PG. 1 OF 1


DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.  
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

- GENERAL NOTES: Installation is similar for both S-D, P-D, W-D and P-S/D-4400 fixtures.
- A) THIS INSTRUCTION SHEET IS USED WITH THE APPLICABLE FIXTURE INSTRUCTION SHEETS.
  - B) END CAPS ARE ATTACHED TO EACH END OF AN INDIVIDUALLY MOUNTED FIXTURE AND AT BOTH ENDS OF A ROW OF FIXTURES.

**INSTRUCTIONS:**

Align studs on End Cap with End Header holes in fixture and secure with (2) 8-32 hex nuts shipped with end caps.

Make sure end caps are flush and square with fixture before tightening nuts.



LITECONTROL

100 HAWKS AVENUE - HANSON MA 02341, (781-294-0100)